



THE ELECTRIC HEATER COMPANY

45 SEYMOUR STREET / P.O. BOX 288

STRATFORD, CT 06615-0288

TEL: (203) 378-2659 FAX: (203) 378-3593

<http://www.hubbellheaters.com>

SERVICE BULLETIN

Bulletin No. 009

Issue Date: May 8, 2006

Product: Model J Booster Heaters

Component: T1000 Control Board

Purpose: To provide field service technicians with specific information regarding product service or operation.

Background: In rare instances, the T1000 mounting screws/bushings could be over-tightened thus decreasing the air gap between the T1000 and the mounting plate and creating a potential path to ground causing a premature failure of the T1000. In order to eliminate this rare occurrence, Hubbell has increased the distance between the back of the T1000 and the control mounting plate. This is easily accomplished by the addition of a second rubber bushing and longer screw used to secure the T1000 to the mounting plate.

Current Status: Effective May 8th all new boosters shipped from the factory will incorporate the new design. Furthermore, all replacement T1000's shipped from the factory as of May 8th will be shipped with additional rubber offsets and longer screws to be used during installation.

Remarks/Action: None